

SUBARU DPF Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	DPF
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●
Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●

Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●
DPF Function List			
DPF change			
DPF regeneration			
Reading of DPF/engine oil-related learning values:ECM to TOOL			

SUBARU ECM Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	ECM
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●
Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●

Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●

ECM Function List

Air flow sensor learning
Brake Vacuum Pump System Check
Clear Learning Value
ECU Parts Number
EGR valve opening angle learning
Engine Coolant Air Purge Mode
Forced S(Sulfur) Purge
Fuel pump duty learning
GPF(Gasoline Particulate Filter) Change
GPF(Gasoline Particulate Filter) Regeneration
LNT(Lean NOx Trap) Change
Software information
Turbo vanes angle learning
Twin Turbocharger System
VVT Initial Position Learning Value Display
immobiliser System

SUBARU EPB Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	EPB
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●
Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●

Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●
EPB Function List			
Brake Maintenance Mode			
Force Sensor Calibration Mode			
Break-in Parking Brake Drive Mode			
Parking Brake Removal Mode			

SUBARU ETC Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	ETC
Japan	BRZ VEHICLE	2013-2020	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Africa	BRZ VEHICLE	2013-2020	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Europe	BRZ VEHICLE	2013-2020	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Middle East	BRZ VEHICLE	2013-2020	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●
Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●
Asia and Pacific	BRZ VEHICLE	2013-2020	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●

Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
North America (US/Canada)	BRZ VEHICLE	2013-2020	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
Central and South America	BRZ VEHICLE	2013-2020	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
ETC Function List			
Throttle manual matching			

SUBARU INJ Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	INJ
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●
Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●

Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●
INJ Function List			
Injector Adjust			
Injector Code Display			
Read Injector Code (ECM to TOOL)			
Injector Code New Registration (TOOL to ECM)			
Fuel injector injection amount learning			

SUBARU MIS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	MIS
Japan	BRZ VEHICLE	2013-2020	●
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	BRZ VEHICLE	2013-2020	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	BRZ VEHICLE	2013-2020	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	BRZ VEHICLE	2013-2020	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●

Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●
Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	BRZ VEHICLE	2013-2020	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	BRZ VEHICLE	2013-2020	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	BRZ VEHICLE	2013-2020	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●

MIS Function List

ABS Sequence Control Mode
AT learning mode
AWD ON/OFF switching mode
Actuator Initialization
Auto Dimmer Cancel setting
Auto Light Sensitivity Adjustment
Auto Wiper at startup Setting
Auto Wiper/INT Setting
Brake Lamp Lighting Operation
Camera information confirmation
Clear AT learning value

Clear Diagnostic Code(s)and Window Glass Position
Clear Vehicle Specific Assist Map
Clear adjustment value
Clutch Engagement Position Setting
Clutch Sensor Calibration Mode
Coarse adjustment
Collation result history Clear
Cruise control 1 Brake Pressure Forced Pressor Mode
Cruise control 2 Brake Pressure Forced Pressor Mode
Cruise control 3 Brake Pressure Forced Pressor Mode
Cruise control 4 Brake Pressure Forced Pressor Mode
Cruise control 5 Brake Pressure Forced Pressor Mode
Cruise control 6 Brake Pressure Forced Pressor Mode
Distance correction
Driving Accumulator and Lowering Pressure
ECU Parts Number Driver side
ECU Parts Number Passenger side
ECU Serial Number Driver side
ECU Serial Number Passenger side
Electric Parking Brake Compulsion Release Mode
Electric driven compressor break-in drive
Erase Backup Memory
Expansion Valve Fully Open Mode
Expansion Valve Initialize Mode
Fog Light Lighting Test
Function Check Sequence
Initialization of function setting
Keyless ID addition registration
Keyless ID renewal
LAN connection unit Reregistration
Learning Offset of Liner Solenoid Valve
Map Information
Memory Initialization
Meter initialization
Mode transition
Parameter Initialization Mode
Power supply auto OFF cancel
Prohibiting Motor Control
RADAR Alignment
ROM ID
Read Control module setting information
Readout the number of keyless ID registration
Rear differential inspection mode
Record Clear
Refrigerant Filling Mode
Rezeroing
SCU forced collation mode
Sensitivity Adjustment Mode
Sensor ID
Sensor initial setting
Simple Calibration of Front Camera
Simple Calibration of Left Side Camera
Simple Calibration of Rear Camera
Simple Calibration of Right Side Camera

Software information
Systemu Initialization
Trouble Factor Code Clear
USB Connection Check
Ultrasonic Motion Sensor Menu
VDC Check Mode
VIN No.
VSC (VDC) Centering Mode
Variable compressor break-in drive
Visual Confirmation
WiFi Device Connection Initialization
Wiper link Auto Light Setting
Wireless diagnosis mode
Zero setting mode of Pressure sensor

SUBARU OIL Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	OIL
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●
Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●

Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●
OIL Function List			
Engine oil change			
Oil change (Reset Without Tool)			
Oil service light reset			

SUBARU SAS Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	SAS
Japan	BRZ VEHICLE	2013-2020	●
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	BRZ VEHICLE	2013-2020	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	BRZ VEHICLE	2013-2020	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	BRZ VEHICLE	2013-2020	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●

Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●
Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	BRZ VEHICLE	2013-2020	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	BRZ VEHICLE	2013-2020	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	BRZ VEHICLE	2013-2020	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●

SAS Function List

ABS Sequence Control Mode
Calibration ID
Longitudinal G sensor and lateral G sensor 0 point setting mode
Set mode Str. A. Sen. N&Lat. GSen. Op
Torque sensor adjust
VDC Check Mode
Zero setting mode of Pressure sensor

SUBARU TCM Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	TCM
Japan	BRZ VEHICLE	2013-2020	●
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	BRZ VEHICLE	2013-2020	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	BRZ VEHICLE	2013-2020	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	BRZ VEHICLE	2013-2020	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●

Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●
Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	BRZ VEHICLE	2013-2020	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	BRZ VEHICLE	2013-2020	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	BRZ VEHICLE	2013-2020	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●

TCM Function List

ECU Parts Number
ATF deterioration degree indication
Inspection mode after ATF, T/M exchange
ATF deterioration writing TOOL to TCM(manual input)
AWD ON/OFF switching mode
Clear the AT learned information
Clear Memories 2
ATF level adjustment mode

SUBARU TPM Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	TPCM
Japan	EXIGA	2009-2018	●
Japan	Forester	1998-2021	●
Japan	Impreza	1998-2021	●
Japan	XV	1998-2021	●
Japan	Legacy	1998-2021	●
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Japan	Tribeca	2005-2014	●
Japan	DEX	--	●
Japan	TRAVIQ	--	●
Japan	Others	--	●
Africa	ASCENT	2019-2021	●
Africa	EVOLTIS	2019-2021	●
Africa	BRZ VEHICLE	2013-2020	●
Africa	Forester	1998-2021	●
Africa	Impreza	1998-2021	●
Africa	XV	1998-2021	●
Africa	Levorg	1998-2021	●
Africa	WRX	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Africa	Tribeca	2005-2014	●
Africa	Others	--	●
Europe	ASCENT	2019-2021	●
Europe	EVOLTIS	2019-2021	●
Europe	BRZ VEHICLE	2013-2020	●
Europe	Forester	1998-2021	●
Europe	Impreza	1998-2021	●
Europe	XV	1998-2021	●
Europe	Levorg	1998-2021	●
Europe	WRX	1998-2021	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Europe	Tribeca	2005-2014	●
Europe	Others	--	●
Middle East	ASCENT	2019-2021	●
Middle East	EVOLTIS	2019-2021	●
Middle East	BRZ VEHICLE	2013-2020	●
Middle East	Forester	1998-2021	●
Middle East	Impreza	1998-2021	●
Middle East	XV	1998-2021	●
Middle East	WRX	1998-2021	●
Middle East	Levorg	1998-2021	●
Middle East	Legacy	1998-2022	●

Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Middle East	Tribeca	2005-2014	●
Middle East	Others	--	●
Asia and Pacific	ASCENT	2019-2021	●
Asia and Pacific	EVOLTIS	2019-2021	●
Asia and Pacific	BRZ VEHICLE	2013-2020	●
Asia and Pacific	Forester	1998-2021	●
Asia and Pacific	Impreza	1998-2021	●
Asia and Pacific	XV	1998-2021	●
Asia and Pacific	Levorg	1998-2021	●
Asia and Pacific	WRX	1998-2021	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
Asia and Pacific	Tribeca	2005-2014	●
Asia and Pacific	Others	--	●
North America (US/Canada)	ASCENT	2019-2021	●
North America (US/Canada)	BRZ VEHICLE	2013-2020	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Forester	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
North America (US/Canada)	WRX	1998-2021	●
North America (US/Canada)	Tribeca	2005-2014	●
North America (US/Canada)	Others	--	●
Central and South America	ASCENT	2019-2021	●
Central and South America	EVOLTIS	2019-2021	●
Central and South America	BRZ VEHICLE	2013-2020	●
Central and South America	Forester	1998-2021	●
Central and South America	Impreza	1998-2021	●
Central and South America	XV	1998-2021	●
Central and South America	Levorg	1998-2021	●
Central and South America	WRX	1998-2021	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●
Central and South America	Tribeca	2005-2014	●
Central and South America	Others	--	●
TPM Function List			
ID registration			
ID registration(With Active Tool)			
ID registration(With Sensor ID)			
TPMS ID Read			
Transmitter ID data monitor			
Transmitter ID regist			

SUBARU BLD Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Area	Vehicle	Year	BLD
Japan	WRX	1998-2021	●
Japan	Levorg	1998-2021	●
Africa	Legacy	1998-2022	●
Africa	Liberty	1998-2022	●
Africa	Outback	1998-2022	●
Europe	Legacy	1998-2022	●
Europe	Liberty	1998-2022	●
Europe	Outback	1998-2022	●
Middle East	Legacy	1998-2022	●
Middle East	Liberty	1998-2022	●
Middle East	Outback	1998-2022	●
Asia and Pacific	Legacy	1998-2022	●
Asia and Pacific	Liberty	1998-2022	●
Asia and Pacific	Outback	1998-2022	●
North America (US/Canada)	Crosstrek	1998-2021	●
North America (US/Canada)	Impreza	1998-2021	●
North America (US/Canada)	Legacy	1998-2022	●
North America (US/Canada)	Outback	1998-2022	●
Central and South America	Legacy	1998-2022	●
Central and South America	Liberty	1998-2022	●
Central and South America	Outback	1998-2022	●

BLD Function List

Brake Air Bleeding

SUBARU Diagnostic Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Model Years			
FORESTER	-2018			
IMPREZA	-2018			
LEGACY	-2018			
OUTBACK	-2018			
PLEO	-2018			
R2	-2018			
VIVIO	-2018			
System	EcuInfo	Read Codes	Erase Codes	Live Data
ECM (Engine Control System)	●	●	●	●
HPC (Hybrid Powertrain Control)	●	●	●	●
TCM (Transmission Control System)	●	●	●	●
ABS (Brake Control System)	●	●	●	●
BVP (Brake Vacuum Pump)	●	●	●	●
SRS (Supplemental Inflatable Restraint System)	●	●	●	●
AC (Air Condition System)	●	●	●	●
METER (Combination Meter System)	●	●	●	●
IMMO (Immobiliser)	●	●	●	●
SSP (Air Suspension System)	●	●	●	●
EPB (Parking Brake System)	●	●	●	●
CCS (Cruise Control System)	●	●	●	●
HVB (High Voltage Battery)	●	●	●	●
TPM (Tire pressure monitor)	●	●	●	●
LT (Headlight / Foglight)	●	●	●	●
ASS (Auto Start Stop)	●	●	●	●
BCM (Body Control System)	●	●	●	●
EPS (Electric Power steering)	●	●	●	●
CS (CAN System)	●	●	●	●
DM (Drive Motor)	●	●	●	●
ALAWS (Automatic Light And Wiper System)	●	●	●	●
DCCD (Driver's Control Center Differential)	●	●	●	●
(ES) EyeSight	●	●	●	●
KLE (Keyless Entry)	●	●	●	●
KAS (Keyless Access System) (Collation ECM)	●	●	●	●
KAS (Keyless Access System) (Power Supply ECM)	●	●	●	●
KAS (Keyless Access System) (G/W ECM)	●	●	●	●
IUM (Integrated Unit Mode)	●	●	●	●
INF (Infotainment)	●	●	●	●
MFD (Multifunction Display)	●	●	●	●
ODS (Occupant Detection System)	●	●	●	●
PSM (Power Seat Memory)	●	●	●	●
PRG (Power Rear Gate)	●	●	●	●
PWD (Power Window Driver)	●	●	●	●
PWP (Power Window Passenger)	●	●	●	●
PWS (Power Window Switch)	●	●	●	●
RABL (RADAR ASSY B&S RH System)	●	●	●	●
RABL (RADAR ASSY B&S LH System)	●	●	●	●
RAB (Reverse Automatic Braking)	●	●	●	●
SMT (Keyless Access with Push Button Start)	●	●	●	●
TLM (Telematics)	●	●	●	●